

GASKET PART NUMBERS FOR APPLICABLE PRODUCT MODELS

Current as of 2023/2/21

Confirm the first 3-4 alphabets of the product model number before purchasing the part.

PART NUMBER	COLOR	PART NAME	APPLICABLE PRODUCT MODEL (● represents an alphabet. ※The numbers indicate the size (capacity) of the product.)	ILLUSTRATION (typical example)
SP1	6B	LID GASKET	SM-WA, SM-WG, SM-WP, SM-WR	
BB395009M	00	LID GASKET	SD-A●, SD-B●, SD-E●, SP-H●	
BB395112M	00	STOPPER GASKET	SD-A●(※08,10), SD-E●(※08,10), SD-F●(※08,10)	
BB474009M	00	LID GASKET	SM-S●, SM-T●	
BB468026M	00	STOPPER GASKET	SM-S●, SM-X●	
567773	01	STOPPER COVER GASKET	SD-A●, SD-B●, SD-E●, SP-H●, ST-C●, ST-J●, ST-P●, ST-R●	
BB402009M	00	LID GASKET	SM-K●	
BB412006M	00	VALVE GASKET	SM-EB, SM-EC, SM-ED, SM-JB, SM-JC, SM-JD, SM-JE, SM-JF, SM-JY, SL-GG, SL-GH, SL-XD, SL-XE, SW-G●, SW-H●, SW-J●, SW-S●	
BB402020M	00	STOPPER GASKET	SM-K●	
BB183001M	01	STOPPER GASKET	SD-A●(※13, 15), SD-E●(※15), SD-F●(※15), SC-LA, SC-LB, SC-LC, SC-LD, SC-LE, SC-LF, SC-MA, SC-MB, SC-MS, SC-MT, SC-MZ, SC-ZS, SJ-S●, SJ-TA, SJ-TB, SJ-TC, SJ-TD, SJ-TE, SJ-TJ, SJ-YV, SM-FA, ST-A●, ST-D●, ST-E●, ST-F●, ST-G●, ST-J●, ST-L●, ST-MA, ST-P●, ST-ZA, ST-ZB, ST-ZC, ST-ZD, ST-ZE, ST-ZF	
BB640025M	00	STOPPER GASKET	SM-L●, SM-T●, SP-J●, SD-C●, SD-JK, SJ-JS	
BB431012M	00	STOPPER GASKET	SM-JB, SM-JC, SM-JD, SM-JE, SM-JF, SM-JY	
BB478039M	01	STOPPER GASKET	SP-H●, SC-LG, SC-LH, SC-MC, SC-ZT, SJ-TG, ST-ZG, ST-ZH	
BB674011M	00	LID GASKET	SD-F●	
BB656016M	00	LID GASKET	SP-J●, SD-JK	
BB402019M	00	STOPPER COVER GASKET	SM-K●	